

YAMAHA


PARTS CATALOGUE

JMPB

FS1SE'82 (5A3)

HOLLAND

125A3-341E1



A3

FOREWORD

This Parts Catalogue is related to the parts in use for the Yamaha FS1SE'82 (5A3).
When you are ordering replacement parts for the FS1SE'82 (5A3), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.
It is advisable that according to the Yamaha Parts News you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

U.R.	Use size (thickness) and/or number as required.
U.N.	Use as many as you need.
A.P.	Alternate Parts
L.M.	Local Made
F#	Frame No. (Applicable machine No.)

3. The parts marked with (*) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.
4. Parts, which are to be supplied in the form of assemblies, are listed with an indention of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE CARBURETOR ASS'Y
 . JET, pilot
 . NOZZLE, main

5. Indication of No. of constituent parts for assembly



The numeral appearing to the right of each constituent part under the description indicates the quantity of such parts for each individual assembly unit.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2F5-83310-60	FRONT FLASHER LIGHT ASS'Y	2	
115-83311-60	. BULB (6V-18W)	1	
1M1-83309-60	. REFLECTOR	1	

6. Initial Serial No. and Color Code

(A) Frame Serial No.	5A3-050101 and following
(B) Engine Serial No.	5A3-050101 and following



Color Code	Color Name	Abbreviate
7J	New Ruby Red	NRR
29	Candy Blue	CB


7. Applicable colors of graphics are represented in the "Remarks" column by the letter(s) appropriately picked out of the full word(s) showing such colors.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2N4-24110-00-X5	FUEL TANK COMP.	1	MAXIM RED
3J1-24240-10	. GRAPHIC, fuel tank set	1	for MXR

FIG. 1 CYLINDER


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3E8-11111-00	HEAD, cylinder 1	1	
2	517-11181-00	GASKET, cylinder head 1	1	
3	94701-00039	PLUG, sPark (NGK B6HS)	1	
4	3E8-11311-00	CYLINDER 1	1	
5	3E1-11351-00	GASKET, cylinder	1	
6	90116-06026	BOLT, stud	4	
7	90179-06337	NUT	4	



5A1310-2010

B2

FIG. 2 CRANKSHAFT·PISTON




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3E8-11400-00	CRANKSHAFT ASSY	1	
2	3E8-11412-00	•CRANK 1	1	
3	3E8-11422-00	•CRANK 2	1	
4	538-11651-01	•ROD, connecting	1	
5	257-11681-00	•PIN, crank 1	1	
6	93310-41809	•BEARING, cylindrical	1	
7	3E8-11631-00-96	PISTON (STD)	1	
	3E8-11635-00	PISTON (1ST O/S 0.25MM)	1	AP
	3E8-11636-00	PISTON (2ND O/S 0.50MM)	1	AP
8	260-11610-02	PISTON RING SET (STD)	1	
	260-11610-12	PISTON RING SET (1ST O/S)	1	AP
	260-11610-22	PISTON RING SET (2ND O/S)	1	AP
9	93310-11268	BEARING, cylindrical	1	
10	102-11633-02	PIN, Piston	1	
11	93450-13022	CIRCLIP	2	
12	93306-20418	BEARING (B6204CS)	1	
13	93102-20009	OIL SEAL	1	
14	93306-30302	BEARING (B6303C3)	1	
15	90280-03017	KEY, woodruff	1	



FIG. 3 FLY WHEEL MAGNETO

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A3-81300-20	FLYWHEEL MAGNETO ASSY	1	
2	5A4-81350-20	•ROTOR ASSY	1	
3	257-81309-21	•BASE, magneto	1	
4	511-81312-20	•COIL, source	1	
5	5A3-81313-20	•COIL, lighting 1	1	
6	2A6-81321-20	•CONTACT BREAKER ASSY	1	
7	1K8-81325-20	•CONDENSER 1	1	
8	116-81331-20	•LUBRICATOR	1	
9	5A4-81315-20	•LEAD WIRE ASSY	1	
10	97602-04125	•SCREW, Pan head with washer	4	
11	110-81346-21	•SCREW, Pan head	1	
12	110-81347-21	•SCREW, Pan head	1	
13	110-81345-21	•SCREW, Pan head	1	
14	98701-05016	SCREW, flat head	2	
15	90201-12535	WASHER, Plate	1	
16	92901-12100	WASHER, sPring	1	
17	90170-12175	NUT	1	




5A1310-2030

B4

FIG. 4 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3F2-13100-00	OIL PUMP ASSY	1	
2	137-13137-00-03	•SHIM (0.3T)	1	UR
	137-13137-00-05	•SHIM (0.5T)	1	UR
	137-13137-00-10	•SHIM (1.0T)	1	UR
3	137-13138-01	•PLATE, adjusting	1	
4	92901-05100	•WASHER, sPring	1	
5	95301-05600	•NUT	1	
6	98901-04008	•SCREW, bind	1	
7	90430-04004	•GASKET	1	
8	93505-32002	•BALL	1	
9	90501-02217	•SPRING, comPression	1	
10	353-13552-01	•NOZZLE	1	
11	90468-02033	•CLIP	1	
12	90445-05019	•HOSE	1	
13	90468-02033	CLIP	1	
14	257-13175-00	SHAFT, worm	1	
15	90201-08624	WASHER, plate	1	
16	126-13116-00	GASKET, PumP case	1	
17	98501-05016	SCREW, Pan head	2	
18	93101-10001	OIL SEAL	1	
19	137-13176-00	METAL, worm shaft outer	1	
20	257-13178-00	GEAR, PumP drive (30T)	1	
21	93603-22028	PIN, dowel	1	
22	90201-10138	WASHER, plate	1	
23	90201-10135	WASHER, plate	1	
24	93430-08006	CIRCLIP	1	
25	3F2-13151-00	STAY	1	
26	98501-05008	SCREW, Pan head	2	




5A2342-2040

B5

FIG. 6 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3F5-14101-00	CARBURETOR ASSY 1	1	
2	127-14141-16	•NOZZLE, main	1	
3	127-14143-25	•JET, main (#125)	1	UR STD
	127-14143-24	•JET, main (#120)	1	UR
	127-14143-26	•JET, main (#130)	1	UR
4	470-14185-00	•FLOAT	1	
5	260-14184-00	•GASKET, float chamber	1	
6	93220-08002	•O-RING	1	
7	260-14181-10	•BODY, float chamber 1	1	
8	92501-06018	•SCREW, Pan head	1	
9	260-14190-12	•NEEDLE VALVE ASSY	1	
10	127-14123-00	•SCREW, air adjusting	1	
11	127-14134-00	•SPRING, air adjusting	1	
12	260-14142-25	•JET, Pilot (#25.0)	1	
13	134-14116-03	•NEEDLE	1	
14	91401-12010	•PIN, cotter	1	
15	405-14114-00	•BAR, throttle	1	
16	283-14112-25	•VALVE, throttle 1	1	
17	127-14137-00	•CLIP	1	
18	287-14136-00	•SEAT, spring	1	
19	127-14131-00	•SPRING, throttle valve	1	
20	127-14133-00	•SPRING, throttle stop	1	
21	395-14121-00	•SCREW, throttle stop	1	
22	3F5-14158-00	•TOP, mixing chamber	1	
23	180-14168-00	•CAP, mixing chamber	1	
24	395-14171-00	•PLUNGER, starter	1	
25	156-14135-00	•SPRING, plunger	1	
26	152-14174-00	•CAP, plunger	1	




5A1310-2060

B7

FIG. 6 CARBURETOR


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	353-14138-00	•CLIP, Plunger	1	
28	637-14173-00	•COVER, Plunger cap	1	
29	304-14261-00	•HOLDER	1	
30	91401-16015	•PIN, cotter	1	
31	127-14125-01	•SCREW	1	
32	95302-05600	•NUT	1	
33	90445-05013	HOSE	1	
34	90445-05015	HOSE	1	



5A1310-2060

B8

FIG. 7 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A3-14611-00	PIPE, exhaust 1	1	
2	1L4-14612-00	NUT, ring	1	
3	132-14613-00	GASKET, exhaust Pipe	1	
4	1J5-14714-00	GASKET, muffler	1	
5	1J5-14713-00	NUT, muffler joint	1	
6	5A3-14710-10	MUFFLER ASSY 1	1	
7	296-14753-02	•SILENCER, exhaust	1	
8	92901-05100	•WASHER, sPring	1	
9	95301-05600	•NUT	1	
10	97301-08016	BOLT	1	
11	92901-08100	WASHER, sPring	1	




5A1310-2070

B9

FIG. 8 CRANKCASE


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	257-15111-01	CRANKCASE 1	1	
2	90338-26008	PLUG	1	
3	90334-10006	PLUG, straight	1	
4	92501-06030	SCREW, Pan head	2	
5	92501-06045	SCREW, Pan head	1	
6	92501-06050	SCREW, Pan head	3	
7	92501-06060	SCREW, Pan head	3	
8	92501-06065	SCREW, Pan head	1	
9	91830-22016	PIN, dowel	2	
10	92501-06055	SCREW, Pan head	2	
11	378-15121-60	CRANKCASE 2	1	
12	90340-12005	PLUG, straight screw	1	
13	90430-12038	GASKET	1	
14	498-15371-00	BREATHER	1	
15	90446-07009	HOSE	1	
16	378-15359-60	HOUSING, oil seal	1	
17	93103-25078	OIL SEAL	1	
18	92501-06014	SCREW, Pan head	3	



5A2342-2080

B10

FIG. 9 CRANKCASE COVER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	283-15411-01	COVER, crankcase 1	1	
2	92501-06045	SCREW, Pan head	2	
3	92501-06040	SCREW, Pan head	1	
4	92501-06050	SCREW, Pan head	1	
5	91830-21014	PIN, dowel	2	
6	164-15415-00	COVER, generator	1	
7	98501-04006	SCREW, Pan head	2	
8	3F5-15421-00	COVER, crankcase 2	1	
9	92501-06030	SCREW, Pan head	6	
10	92501-06040	SCREW, Pan head	1	
11	378-15451-60	GASKET, crankcase cover	1	
12	91830-21014	PIN, dowel	2	
13	90480-12012	GROMMET	1	
14	315-15362-01	PLUG, oil level	1	
15	257-15413-00	COVER, carburetor	1	
16	257-15463-00	GASKET, carburetor cover 2	1	
17	92501-06018	SCREW, Pan head	4	
18	3E8-15428-00-35	COVER, chain case 2	1	silver
19	92501-06008	SCREW, Pan head	3	
20	467-15435-00	EMBLEM	1	
21	5A3-15435-00	EMBLEM	1	



5A3341-2090

B11




B12

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	305-15660-02	KICK AXLE ASSY	1	
2	305-15641-00	GEAR, kick (26T)	1	
3	90468-26048	CLIP	1	
4	117-15644-00	SHIM	1	
5	93410-25017	CIRCLIP	1	
6	132-15664-01	GUIDE, sPring	1	
7	90508-26136	SPRING, torsion	1	
8	132-15676-01	COVER, sPring	1	
9	93410-15005	CIRCLIP	1	
10	93109-15001	OIL SEAL	1	
11	257-15668-00	STOPPER	1	
12	5A3-15620-00	KICK CRANK ASSY	1	
13	283-15612-01	•LEVER, kick	1	
14	156-15618-01	•COVER, kick lever	1	
15	90504-18005	•SPRING, comPression	1	
16	90209-10108	•WASHER	1	
17	93440-10028	•CIRCLIP	1	
18	97311-06025	BOLT	1	
19	90201-13202	WASHER, Plate	1	
20	90206-15021	WASHER, wave	1	
21	257-15651-01	GEAR, kick idle (26T)	1	
22	132-15653-00-10	WASHER	1	UR
	132-15653-00-12	WASHER	1	UR
	132-15653-00-14	WASHER	1	UR
23	93410-13004	CIRCLIP	1	

FIG. 11 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	257-16301-03	CLUTCH ASSY	1	
2	257-16150-03	•PRIMARY DRIVEN GEAR COMP.	1	
3	122-16164-00	•PLATE, thrust 2	1	
4	257-16371-01	•BOSS, clutch	1	
5	131-16321-00	•PLATE, friction	2	
6	257-16324-00	•PLATE, clutch 1	1	
7	257-16351-00	•PLATE, Pressure 1	1	
8	90501-20122	•SPRING, compression	4	
9	90119-05001	•BOLT, with washer	4	
10	90208-12015	WASHER, conical spring	1	
11	90170-12060	NUT	1	
12	257-16111-01	GEAR, Primary drive (19T)	1	
13	90282-05005	KEY, straight	1	
14	90208-12015	WASHER, conical spring	1	
15	90179-12244	NUT	1	
16	122-16164-00	PLATE, thrust 2	1	
17	90560-17150	SPACER	1	
18	137-16356-00	ROD, Push 1	1	
19	93503-16010	BALL	1	
20	257-16357-00	ROD, Push 2	1	
21	93501-04011	BALL	1	
22	90113-06009	BOLT, set	1	
23	95301-06700	NUT	1	
24	257-16341-00	SCREW, Push	1	
25	257-16342-00	LEVER, Push	1	
26	90506-07066	SPRING, tension	1	
27	132-16346-00	HOOK, spring	1	
28	257-15389-00	SEAL, Push rod	1	




5A3341-2110

B13

FIG. 11 CLUTCH


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	93108-15001	OIL SEAL	1	



5A3341-2110

B14

FIG. 12 TRANSMISSION 1



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	257-17411-01	AXLE, main (13T)	1	
2	257-17121-00	GEAR, 2nd Pinion (18T)	1	
3	257-17131-01	GEAR, 3rd Pinion (23T)	1	
4	257-17141-00	GEAR, 4th Pinion (26T)	1	
5	93440-16030	CIRCLIP	1	
6	93410-13004	CIRCLIP	1	
7	3E8-17420-00	DRIVE AXLE ASSY	1	
8	257-17211-00	GEAR, 1st wheel (40T)	1	
9	257-17221-01	GEAR, 2nd wheel (34T)	1	
10	257-17231-00	GEAR, 3rd wheel (30T)	1	
11	257-17219-00	SHIM (0.6T)	1	
12	93410-13004	CIRCLIP	1	
13	93306-20303	BEARING (B6203Z)	1	
14	93306-30301	BEARING (B6303)	1	
15	257-17471-01	PLATE, cover	1	
16	92501-06012	SCREW, Pan head	2	
17	93440-16030	CIRCLIP	1	
18	257-17461-21	SPROCKET, drive (12T)	1	UR STD
	257-17461-11	SPROCKET, drive (11T)	1	UR
	257-17461-31	SPROCKET, drive (13T)	1	UR
19	93410-16007	CIRCLIP	1	
20	93102-17187	OIL SEAL	1	




5A3341-2120

B15

FIG. 13 TRANSMISSION 2

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	283-17491-20	SPROCKET, drive	1	
2	283-17492-00	DOG, transmission shift	1	
3	90501-12090	SPRING, comPression	1	
4	283-17494-00	FORK, transmission shift	1	
5	90501-10078	SPRING, comPression	1	
6	283-17495-00	LEVER, transmission shift	1	
7	283-17496-00	KNOB, transmission shift	1	
8	93430-08006	CIRCLIP	1	
9	93306-00203	BEARING (B6002)	1	
10	93410-16007	CIRCLIP	1	
11	93410-15005	CIRCLIP	1	




5A3341-2130

C2

FIG. 14 SHIFT CAM.FORK

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	257-18540-60	SHIFT CAM ASSY	1	
2	93604-22050	•PIN, dowel	4	
3	91609-40016	•PIN, sPring	1	
4	164-18561-00	•PLATE, side 1	1	
5	98501-05012	•SCREW, Pan head	1	
6	92901-05100	•WASHER, sPring	1	
7	136-18542-00	•POINT, neutral	1	
8	93605-20043	•PIN, dowel	1	
9	93440-32017	•CIRCLIP	1	
10	259-18511-01	FORK, shift 1	1	
11	257-18512-01	FORK, shift 2	1	
12	90250-06013	PIN, straight	2	
13	257-18531-00	BAR, shift fork Guide 1	1	
14	257-18534-00	BAR, shift fork Guide	1	
15	93430-08006	CIRCLIP	3	
16	132-18140-01	STOPPER LEVER ASSY	1	
17	90109-06001	BOLT	1	
18	90506-09112	SPRING, tension	1	




5A3341-2140

C3

FIG. 15 SHIFT SHAFT•PEDAL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	257-18101-01	SHIFT SHAFT ASSY	1	
2	90506-09009	•SPRING, tension	1	
3	90508-32207	SPRING, torsion	1	
4	90149-08094	SCREW	1	
5	95301-08600	NUT	1	
6	170-18111-01-91	PEDAL, shift	1	uni chrome
7	132-18113-01	COVER, shift Pedal	1	
8	97321-06020	BOLT	1	
9	93101-12004	OIL SEAL	1	
10	90201-12575	WASHER, Plate	1	
11	93430-10016	CIRCLIP	1	




5A3341-2150

C4

FIG. 16 FRAME. TOOL


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-21110-00-33	FRAME COMP.	1	yamaha black
2	95826-08120	BOLT, flange	2	
3	95826-08090	BOLT, flange	1	
4	95826-08100	BOLT, flange	1	
5	95706-08100	NUT, flange	4	
6	92906-08100	WASHER, sPring	4	
7	90480-13203	GROMMET	1	
8	3F2-21288-00	GUIDE, cable	1	
9	97306-06012	BOLT	1	
10	92906-06100	WASHER, sPring	1	
11	260-28100-10	TOOL KIT	1	



FWD

5A3341 - 2 160

C5




5A3341-2170

FIG. 17 FRONT FENDER-REAR FENDER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A3-21510-00-93	FRONT FENDER COMP.	1	chrome-plated
2	97301-08012	BOLT	4	
3	92901-08100	WASHER, sPring	4	
4	1A0-21518-00	HOLDER, cable	1	
5	98501-05012	SCREW, Pan head	2	
6	92901-05600	WASHER, Plate	2	
7	95301-05600	NUT	2	
8	92901-05100	WASHER, sPring	2	
9	5A3-21610-01-36	REAR FENDER COMP.	1	clean white
10	90480-12013	GROMMET	2	
11	97321-08016	BOLT	2	
12	92901-08100	WASHER, sPring	2	
13	97321-06014	BOLT	1	
14	92901-06100	WASHER, sPring	1	
15	92901-06200	WASHER, Plain	1	
16	5A1-21645-00	STAY, rear	1	
17	97301-06016	BOLT	4	
18	92901-06100	WASHER, sPring	4	
19	90338-14120	PLUG	2	
20	92901-06200	WASHER, Plain	4	
21	5A3-21621-00	FLAP	1	
22	97301-05016	BOLT	2	
23	90201-05029	WASHER, Plate	4	
24	95301-05600	NUT	2	
25	90338-06018	PLUG	1	
26	1J7-21717-00	DAMPER, side cover	1	
27	92901-05100	WASHER, sPring	2	

FIG. 18 SIDE COVER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-21711-00	COVER, side 1	1	
2	5A1-21721-00	COVER, side 2	1	
3	90480-11224	GROMMET	1	
4	5A1-21781-00	EMBLEM 1	2	




5A1310-2170

C7

FIG. 19 OIL TANK


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-21750-00	OIL TANK ASSY	1	
2	1Y1-21764-00	•LENS, level gauge	1	
3	1Y1-21763-00	•GASKET, level gauge	1	
4	1Y1-2176A-00	•REFLECTOR, level gauge	1	
5	3L5-21770-01	OIL TANK CAP ASSY	1	
6	5A1-24319-00	PIPE, oil	1	
7	90467-08003	CLIP	2	
8	90480-14052	GROMMET	2	
9	90201-06557	WASHER, Plate	2	
10	97301-06016	BOLT	2	
11	92901-06100	WASHER, sPring	2	
12	5A1-24756-00	COVER, tail	1	
13	90480-13197	GROMMET	2	



5A1310-2180

C8


FIG. 20 REAR ARM.SUSPENSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A3-22110-00-33	REAR ARM COMP.	1	yamaha black
2	102-22123-00	BUSH 1	2	
3	109-22141-00	SHAFT, Pivot	1	
4	122-22151-00	SEAL, Guard	1	
5	90170-10159	NUT	1	
6	5A1-22311-00	CASE, chain	1	
7	98501-05008	SCREW, Pan head	1	
8	92901-05600	WASHER, Plate	1	
9	98506-05020	SCREW, Pan head	1	
10	92906-05600	WASHER, Plate	1	
11	120-27431-00	FOOTREST, rear 1	2	
12	120-27433-00	COVER, rear footrest	2	
13	90201-20279	WASHER, Plate	2	
14	90240-06009	PIN, clevis	2	
15	91401-16015	PIN, cotter	2	
16	5A1-22210-01	SHOCK ABSORBER ASSY, rear	2	
17	90201-10140	WASHER, Plate	6	
18	90176-10013	NUT, crown	4	
19	90101-10521	BOLT	2	
20	92901-10200	WASHER, Plain	2	

5A3341-2200


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	283-27810-00	CRANK, Pedal	1	
2	1V6-27821-00	PEDAL, crank (R.H)	1	
3	5A3-27812-00	AXLE, Pedal	1	
4	5A3-27824-00	PIPE, shaft	1	
5	90501-18464	SPRING, comPression	1	
6	90251-07001	PIN, taPered	1	
7	90249-06005	PIN	1	
8	95301-06600	NUT	1	
9	92901-06600	WASHER, Plate	1	
10	93440-25019	CIRCLIP	1	
11	1F1-27850-00	PEDAL ASSY (L.H)	1	
12	1F1-27860-00	PEDAL ASSY (R.H)	1	
13	94504-10040	CHAIN, drive (DID410 40L)	1	
14	94604-10001	JOINT, chain	1	
15	93430-15023	CIRCLIP	1	
16	283-27826-00	COVER, Pedal	1	



5A3341-2210

C10

FIG. 22 STEERING



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	156-23411-00	RACE, ball 1	1	
2	5A1-23435-00-98	CROWN, handle	1	low gloss black
3	90209-10021	WASHER	1	
4	90105-10006	BOLT, washer based	1	
5	90179-25051	NUT	1	
6	183-23411-00	RACE, ball 1	1	
7	183-23412-00	RACE, ball 2	1	
8	156-23412-00	RACE, ball 2	1	
9	93501-04011	BALL	38	
10	136-23415-00	COVER, ball race 1	1	
11	5A1-23441-00	HOLDER, handle upper	2	
12	462-23442-00-98	HOLDER, handle lower	2	low gloss black
13	95301-10600	NUT	2	
14	92901-10100	WASHER, spring	2	
15	92901-10600	WASHER, plate	2	
16	90119-06017	BOLT, with washer	4	
17	5A1-23408-00	STEERING LOCK ASSY	1	
18	90152-05009	SCREW, countersunk	2	
19	5A1-23327-00	STAY, flasher	1	
20	5A1-23328-00	STAY, flasher	1	
21	5A1-23116-00	GUIDE, cover lower	2	
22	90430-27165	GASKET	2	
23	4U5-23122-00	COVER, outer 1	1	



5A1310-2200

C11

ack

black

FIG. 23 FRONT FORK


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-23100-00	FRONT FORK ASSY	1	
2	5A1-23110-00	•INNER TUBE COMP.1	2	
3	5A1-23107-00-35	•OUTER TUBE COMP. (R.H)	1	silver
4	5A1-23106-00-35	•OUTER TUBE COMP. (L.H)	1	silver
5	90101-10514	•BOLT	2	
6	93210-10475	•O-RING	2	
7	90201-103E6	•WASHER, Plate	2	
8	5A1-23125-00	•METAL, slide 1	2	
9	5A1-23146-00	•WASHER, oil seal	2	
10	93110-27009	•OIL SEAL	2	
11	93450-40070	•CIRCLIP	2	
12	5A1-23340-00-33	•UNDER BRACKET COMP.	1	yamaha black
13	5A1-23141-00	•SPRING, front fork	2	
14	90201-103E9	•WASHER, Plate	2	
15	5A1-23144-00	•SEAL, dust	2	
16	5A1-23118-00	•SPACER	2	
17	97321-10035	•BOLT	2	
18	92901-10100	•WASHER, sPring	2	
19	5A1-23318-00	•HOLDER, cable 1	1	



5A1310-2210

C12


FIG. 24 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-24110-00-03	FUEL TANK COMP.	1	UR new ruby red
	5A1-24110-00-04	FUEL TANK COMP.	1	UR candy blue
2	5A1-24240-00	•GRAPHIC SET	1	
3	122-24181-00	DAMPER, locating 1	2	
4	5A1-24181-00	DAMPER, locating 1	1	
5	5A1-24182-00	DAMPER, locating 2	1	
6	90201-06075	WASHER, Plate	1	
7	97301-06016	BOLT	1	
8	4U5-24610-00	CAP ASSY	1	
9	5G0-24500-01	FUEL COCK ASSY 1	1	
10	4X8-24534-00	•SEAL, cock	1	
11	4X8-24565-00	•GASKET	1	
12	4X8-24512-00	•GASKET	1	
13	4X8-24535-00	•SCREW, lever fitting	2	
14	90445-09115	HOSE	1	
15	90445-09089	HOSE	1	
16	90467-08003	CLIP	4	
17	3X0-24161-01	EMBLEM 1	2	
18	90149-06011	SCREW	2	
19	90202-06010	WASHER, Plate	2	

FIG. 25 SEAT

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-W2472-00	DOUBLE SEAT ASSY	1	
2	5A1-24731-00	.COVER, double seat	1	
3	1L9-24741-00	PAD, seat	4	
4	1T4-24741-00	PAD, seat	2	
5	5A1-24715-00	STAY, front	1	
6	5A1-24728-00	BRACKET, seat	1	
7	5A1-24738-00	BRACKET, seat	1	
8	1L9-24723-00	DAMPER, seat	2	
9	90387-07390	COLLAR	2	
10	5A1-24723-00	DAMPER, seat	8	
11	90387-07392	COLLAR	4	
12	90201-06008	WASHER, Plate	6	
13	90119-06016	BOLT, with washer	6	
14	5A1-24705-00	SEAT LOCK ASSY	1	
15	5A1-24760-00	SEAT LEVER ASSY	1	
16	92506-06016	SCREW, Pan head	4	
17	92906-06100	WASHER, sPring	4	




5A1310-2230

C14

FIG. 26 FRONT WHEEL


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	517-25111-00-35	HUB, front	1	silver
2	195-25117-00	SPACER, bearing	1	
3	195-25115-00	FLANGE, spacer 1	1	
4	93106-20001	OIL SEAL	1	
5	93306-30003	BEARING (B6300Z)	2	
6	5A3-25121-00-35	PLATE, brake shoe	1	silver
7	93105-47007	OIL SEAL	1	
8	326-25330-10	BRAKE SHOE COMP.	2	
9	90506-16150	SPRING, tension	2	
10	296-25135-00	GEAR, drive	1	
11	109-25136-00	BUSH	1	
12	296-25138-00	GEAR, meter	1	
13	93104-07003	OIL SEAL	1	
14	183-25149-00	CLUTCH, meter	1	
15	90201-07076	WASHER, plate	1	
16	90201-20269	WASHER, plate	2	
17	93410-20009	CIRCLIP	1	
18	3Y6-25351-00	CAMSHAFT	1	
19	3Y6-2533A-01	PLATE, indicator	1	
20	538-25155-00	LEVER, camshaft 1	1	
21	90101-06278	BOLT	1	
22	95301-06600	NUT	1	
23	109-25104-00	SPOKE SET, front	1	
24	94412-17002	RIM (1.20-17)	1	
25	94125-17259	TIRE (2.50-17)	1	
26	94225-17105	TUBE (2.50-17)	1	
27	94330-17023	BAND, rim (3.00-17)	1	
28	353-25181-03	AXLE, wheel	1	



5A3341-2260

C15

FIG. 26 FRONT WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90387-10277	COLLAR	1	
30	322-25118-00	COVER, hub dust	1	
31	92901-10600	WASHER, Plate	1	
32	90171-10004	NUT, castle	1	
33	91401-20020	PIN, cotter	1	
34	102-25137-00	RING, stop	1	
35	93210-14104	O-RING	1	



5A3341 - 2260

D2

FIG. 27 REAR WHEEL



5A3341-2270


D3

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	462-25311-01-35	HUB, rear	1	silver
2	90560-12170	SPACER	1	
3	102-25315-00	FLANGE, sPacer	1	
4	93306-30101	BEARING (B6301)	2	
5	93106-20002	OIL SEAL	1	
6	93104-21016	OIL SEAL	1	
7	288-25445-10-33	SPROCKET, driven (45T)	1	UR STD
	288-25444-10-33	SPROCKET, driven (44T)	1	yamaha black
	288-25446-10-33	SPROCKET, driven (46T)	1	UR yamaha black
8	90109-08319	BOLT	4	
9	101-25412-00	WASHER	2	
10	90170-08158	NUT	4	
11	1M3-25321-01-35	PLATE, brake shoe	1	silver
12	326-25330-10	BRAKE SHOE COMP.	2	
13	90506-16150	SPRING, tension	2	
14	3E1-25351-00	CAMSHAFT	1	
15	3Y6-2533A-01	PLATE, indicator	1	
16	538-25355-00	LEVER, camshaft	1	
17	90101-06278	BOLT	1	
18	95301-06600	NUT	1	
19	296-25304-00	SPOKE SET, rear	1	
20	94414-17003	RIM (1.40-17)	1	
21	94125-17259	TIRE (2.50-17)	1	
22	94225-17105	TUBE (2.50-17)	1	
23	94330-17023	BAND, rim (3.00-17)	1	
24	94580-13100	CHAIN, drive (DID420M 100L)	1	
25	94604-20001	JOINT, chain	1	
26	102-25371-00	BAR, tension	1	

ck
black
black


FIG. 27 REAR WHEEL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	90109-08183	BOLT	1	
28	95301-08700	NUT	2	
29	92901-08200	WASHER, Plain	1	
30	91401-20015	PIN, cotter	1	
31	92901-08100	WASHER, sPring	1	
32	90468-12007	CLIP	1	
33	5A1-25381-00	AXLE, wheel	1	
34	90171-12005	NUT, castle	1	
35	91401-30025	PIN, cotter	1	
36	90387-12412	COLLAR	1	
37	90387-12670	COLLAR	1	
38	102-25389-00	PULLER, chain 2	2	
39	95301-06600	NUT	2	
40	92901-06100	WASHER, sPring	2	
41	92901-06600	WASHER, Plate	2	



5A3341-2270

D4



5A3341-2280

FIG. 28 HANDLEBAR-CABLE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-26111-00	HANDLEBAR	1	
2	353-26242-00	GRIP (R.H)	1	
3	1V1-26243-00	TUBE, throttle Guide	1	
4	353-26241-00	GRIP (L.H)	1	
5	1V1-26281-00	CAP, grip upper	1	
6	1V1-26282-00	CAP, grip lower	1	
7	98506-05016	SCREW, Pan head	2	
8	5A1-26311-00	CABLE, throttle 1	1	
9	3F2-26312-00	CABLE, throttle 2	1	
10	3F2-26321-00	CABLE, Pump	1	
11	2T5-26261-00	CONNECTOR, cable	1	
12	2T5-26262-00	CAP, cable connector	1	
13	2T5-26273-00	ROTOR	1	
14	2T5-26274-00	GUIDE, rotor	1	
15	2T5-26244-00	SLIDER, throttle	1	
16	2T5-26267-00	PIN	1	
17	90501-05512	SPRING, compression	1	
18	90167-03004	SCREW, tapping	2	
19	156-26329-00	CAP, rubber	1	
20	3F2-21364-00	HOLDER, cable cylinder	1	
21	5A1-26335-00	CABLE, clutch	1	
22	164-26363-00	END, cable	1	
23	90123-08046	BOLT	2	
24	90179-08148	NUT	2	
25	5A3-26341-01	CABLE, brake	1	
26	90123-06010	BOLT	1	
27	90179-06143	NUT	1	
28	92501-06012	SCREW, Pan head	1	

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92901-06100	WASHER, sPring	1	
30	90338-09012	PLUG	1	
31	5A2-26290-10	BACK MIRROR ASSY	1	





FIG. 29 STAND•FOOTREST

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-27111-00-33	STAND, main	1	yamaha black
2	122-27112-00	SHAFT, main stand	1	
3	109-27115-00	LINK, main stand	1	
4	90506-29054	SPRING, tension	1	
5	278-27114-00	STOPPER, main stand	1	
6	5A1-27211-00-91	PEDAL, brake	1	uni chrome
7	90506-20041	SPRING, tension	1	
8	93430-12008	CIRCLIP	1	
9	180-27231-01	ROD, brake	1	
10	90501-10245	SPRING, comPression	1	
11	90249-12008	PIN	1	
12	90179-06176	NUT	1	
13	91401-20015	PIN, cotter	1	
14	92901-06600	WASHER, Plate	2	




5A3341-2290

D7

FIG. 30 FLASHER LIGHT

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-83310-10	FRONT FLASHER LIGHT ASSY 1	2	
2	3M7-83312-10	•LENS, flasher	1	
3	152-83311-10	•BULB (6V-10W)	1	
4	1M1-83318-00	STAY, flasher 1	2	
5	95303-08800	NUT, crown	2	
6	5A1-83330-10	REAR FLASHER LIGHT ASSY 1	2	
7	3M7-83312-10	•LENS, flasher	1	
8	152-83311-10	•BULB (6V-10W)	1	
9	92901-08100	WASHER, sPring	2	
10	95301-08600	NUT	2	




5A1310-2280

D8

FIG. 31 SPEEDOMETER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3F4-83510-F0	SPEEDOMETER ASSY	1	km/h
2	2W0-83520-00	.SOCKET CORD ASSY	1	
3	122-83516-10	.BULB (6V-3W)	2	
4	355-83519-02	BRACKET, meter	1	
5	1M3-83513-00	DAMPER	2	
6	355-83526-00	DAMPER 2	2	
7	355-83522-00	COLLAR	2	
8	90201-06412	WASHER, Plate	2	
9	95301-06600	NUT	2	
10	3R9-83550-50	SPEEDOMETER CABLE ASSY	1	




5A1310-2290

D9

FIG. 32 HEADLIGHT

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	241-84311-00-93	BODY, headlight	1	chrome-Plated
2	150-84153-00	•GROMMET, wireherness	2	
3	482-84110-00	HEADLIGHT UNIT ASSY	1	
4	260-84120-00	•LENS ASSY	1	
5	195-84315-01	•RIM, headlight	1	
6	206-84114-60	•BULB (6V-25/25W)	1	
7	195-84324-00	•SPRING, reflector	3	
8	317-84112-30	•SOCKET	1	
9	90152-05005	SCREW, countersunk	1	
10	97303-08020	BOLT	2	
11	92903-08600	WASHER, Plate	2	
12	92901-08100	WASHER, sPring	2	
13	95301-08700	NUT	2	




5A3341-2320

D10

FIG. 33 TAILLIGHT


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	1X4-84510-90	TAILLIGHT UNIT ASSY	1	
2	1X6-84511-00	•BASE, taillight	1	
3	1X4-84521-90	•LENS, taillight	1	
4	1X4-84524-90	•SCREW, lens fitting	2	
5	1X4-84514-00	•BULB (6V-2W)	1	
6	1X4-84535-00	•BULB (6V-5W)	1	
7	5A3-84551-90-93	BRACKET, licence	1	chrome-Plated
8	92901-05600	WASHER, Plate	2	
9	92901-05100	WASHER, sPring	2	
10	97301-05010	BOLT	2	
11	97303-06016	BOLT	1	
12	92903-06600	WASHER, Plate	1	
13	92903-06100	WASHER, sPring	2	
14	95301-06600	NUT	2	



5A3341-2330

D11

FIG. 34 ELECTRICAL 1




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A1-81975-00	PLATE, rectifier fitting	1	
2	90109-06617	BOLT	1	
3	92501-06012	SCREW, Pan head	1	
4	92901-06100	WASHER, sPring	1	
5	92901-06100	WASHER, sPring	2	
6	95701-06100	NUT, flange	1	
7	90201-062A8	WASHER, Plate	1	
8	353-81970-50	RECTIFIER ASSY	1	UR
	353-81970-63	RECTIFIER ASSY	1	UR
9	98501-05025	SCREW, Pan head	1	
10	92901-05600	WASHER, Plate	1	
11	355-81973-00	COLLAR, rectifier	1	
12	92901-05200	WASHER, Plain	1	
13	95301-05600	NUT	1	
14	4F4-81910-60	VOLTAGE REGULATOR ASSY	1	
15	92501-06015	SCREW, Pan head	1	
16	92901-06100	WASHER, sPring	1	
17	92901-06600	WASHER, Plate	1	
18	104-82110-29	BATTERY ASSY (6N4A-4D)	1	
19	90445-08171	HOSE	1	
20	104-82122-00	SEAT, battery	1	
21	1Y1-82131-00	BAND, battery	1	
22	353-82150-00	FUSE HOLDER ASSY	1	
23	116-82151-00	•FUSE (6V-10A)	1	
24	355-82310-40	IGNITION COIL ASSY	1	
25	95301-06600	NUT	2	
26	512-82370-10	PLUG CAP ASSY	1	with noise sup- Presser
27	5A1-82508-20	MAIN SWITCH ASSY	1	

5A3341-2340

D12

FIG. 34 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	5A1-82514-00	STAY, main switch	1	
29	5A7-82571-01	PANEL, switch	1	
30	90480-13163	GROMMET	1	
31	98501-04012	SCREW, Pan head	2	
32	92901-04100	WASHER, sPring	2	
33	1J7-82530-00	STOP SWITCH ASSY	1	
34	5A1-82539-01	STAY, stoP switch	1	
35	136-82540-00	NEUTRAL SWITCH ASSY	1	
36	90430-11034	GASKET	1	
37	5A3-82590-20	WIRE HARNESS ASSY	1	
38	3K7-81980-00	•DIODE	1	
39	3E1-83350-11	FLASHER RELAY ASSY	1	
40	5A1-83352-00	BRACKET, flasher relay 1	1	
41	92501-06012	SCREW, Pan head	1	
42	92901-06100	WASHER, sPring	1	
43	469-83382-00	BELL	1	
44	1X4-84517-00	CORD, taillight	1	




5A3341-2340

D13


FIG. 35 HANDLE SWITCH•LEVER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	498-82911-00	HOLDER, lever 1	1	
2	214-83912-00	LEVER 1	1	
3	97306-06022	BOLT	1	
4	92906-06100	WASHER, sPring	1	
5	90109-06576	BOLT	1	
6	90201-082A9	WASHER, Plate	1	
7	95606-06100	NUT, u	1	
8	5A1-82920-10	LEVER HOLDER ASSY 2	1	
9	233-83922-30	•LEVER 2	1	
10	90109-06410	•BOLT	1	
11	95601-06100	•NUT, u	1	
12	90201-08083	•WASHER, Plate	1	
13	97306-06022	BOLT	1	
14	92906-06100	WASHER, sPring	1	
15	5A3-83973-00	SWITCH, handle 3	1	
16	98501-05030	•SCREW, Pan head	1	
17	90157-05027	•SCREW, Pan head	1	
18	437-83936-00	BAND, switch cord	4	



5A2342-2330

D14



JMPB
parts

REPAIR KIT

JMPB

parts


FIG. 36 REPAIR KIT

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	538-11650-00	CONNECTING ROD ASSY	1	
2	538-11651-01	•ROD, connecting	1	
3	257-11681-00	•PIN, crank 1	1	
4	93310-41809	•BEARING, cylindrical	1	
5	93310-11268	•BEARING, cylindrical	1	

JMPB parts

INDEX

JMPB *parts*



NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
5A1-W2472-00	25- 1	127-14137-00	6-17	156-15618-01	10-14
3E8-11111-00	1- 1	353-14138-00	6-27	5A3-15620-00	10-12
517-11181-00	1- 2	127-14141-16	6- 2	305-15641-00	10- 2
3E8-11311-00	1- 4	260-14142-25	6-12	117-15644-00	10- 4
3E1-11351-00	1- 5	127-14143-24	6- 3	257-15651-01	10-21
3E8-11400-00	2- 1	127-14143-25	6- 3	132-15653-00-10	10-22
3E8-11412-00	2- 2	127-14143-26	6- 3	132-15653-00-12	10-22
3E8-11422-00	2- 3	3F5-14158-00	6-22	132-15653-00-14	10-22
260-11610-02	2- 8	180-14168-00	6-23	305-15660-02	10- 1
260-11610-12	2- 8	395-14171-00	6-24	132-15664-01	10- 6
260-11610-22	2- 8	637-14173-00	6-28	257-15668-00	10-11
3E8-11631-00-96	2- 7	152-14174-00	6-26	132-15676-01	10- 8
102-11633-02	2-10	260-14181-10	6- 7	257-16111-01	11-12
3E8-11635-00	2- 7	260-14184-00	6- 5	257-16150-03	11- 2
3E8-11636-00	2- 7	470-14185-00	6- 4	122-16164-00	11- 3
538-11650-00	36- 1	260-14190-12	6- 9		11-16
538-11651-01	2- 4	304-14261-00	6-29	257-16301-03	11- 1
	36- 2	5A3-14411-00	5-10	131-16321-00	11- 5
257-11681-00	2- 5	3E8-14417-00	5-18	257-16324-00	11- 6
	36- 3	3E8-14451-00	5-11	257-16341-00	11-24
3F2-13100-00	4- 1	3F2-14453-00	5-16	257-16342-00	11-25
126-13116-00	4-16	3E8-14473-00	5-12	132-16346-00	11-27
137-13137-00-03	4- 2	2F2-14481-00	5-20	257-16351-00	11- 7
137-13137-00-05	4- 2	3E8-14498-00	5-13	137-16356-00	11-18
137-13137-00-10	4- 2	5A3-14611-00	7- 1	257-16357-00	11-20
137-13138-01	4- 3	1L4-14612-00	7- 2	257-16371-01	11- 4
3F2-13151-00	4-25	132-14613-00	7- 3	257-17121-00	12- 2
257-13175-00	4-14	5A3-14710-10	7- 6	257-17131-01	12- 3
137-13176-00	4-19	1J5-14713-00	7- 5	257-17141-00	12- 4
257-13178-00	4-20	1J5-14714-00	7- 4	257-17211-00	12- 8
3F5-13505-00	5- 7	296-14753-02	7- 7	257-17219-00	12-11
353-13552-01	4-10	257-15111-01	8- 1	257-17221-01	12- 9
474-13610-01	5- 1	378-15121-60	8-11	257-17231-00	12-10
314-13613-01	5- 2	378-15359-60	8-16	257-17411-01	12- 1
314-13616-01	5- 3	315-15362-01	9-14	3E8-17420-00	12- 7
378-13621-60	5- 5	498-15371-00	8-14	257-17461-11	12-18
3F5-14101-00	6- 1	257-15389-00	11-28	257-17461-21	12-18
283-14112-25	6-16	283-15411-01	9- 1	257-17461-31	12-18
405-14114-00	6-15	257-15413-00	9-15	257-17471-01	12-15
134-14116-03	6-13	164-15415-00	9- 6	283-17491-20	13- 1
395-14121-00	6-21	3F5-15421-00	9- 8	283-17492-00	13- 2
127-14123-00	6-10	3E8-15428-00-35	9-18	283-17494-00	13- 4
127-14125-01	6-31	257-15433-00	5-22	283-17495-00	13- 6
127-14131-00	6-19	467-15435-00	9-20	283-17496-00	13- 7
127-14133-00	6-20	5A3-15435-00	9-21	257-18101-01	15- 1
127-14134-00	6-11	378-15451-60	9-11	170-18111-01-91	15- 6
156-14135-00	6-25	257-15463-00	9-16	132-18113-01	15- 7
287-14136-00	6-18	283-15612-01	10-13	132-18140-01	14-16

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
259-18511-01	14-10	156-23412-00	22- 8
257-18512-01	14-11	183-23412-00	22- 7
257-18531-00	14-13	136-23415-00	22-10
257-18534-00	14-14	5A1-23435-00-98	22- 2
257-18540-60	14- 1	5A1-23441-00	22-11
136-18542-00	14- 7	462-23442-00-98	22-12
164-18561-00	14- 4	5A1-24110-00-03	24- 1
5A1-21110-00-33	16- 1	5A1-24110-00-04	24- 1
3F2-21288-00	16- 8	3X0-24161-01	24-17
3F2-21364-00	28-20	122-24181-00	24- 3
5A3-21510-00-93	17- 1	5A1-24181-00	24- 4
1A0-21518-00	17- 4	5A1-24182-00	24- 5
5A3-21610-01-36	17- 9	5A1-24240-00	24- 2
5A3-21621-00	17-21	5A1-24319-00	19- 6
5A1-21645-00	17-16	5G0-24500-01	24- 9
5A1-21711-00	18- 1	4X8-24512-00	24-12
1J7-21717-00	17-26	4X8-24534-00	24-10
5A1-21721-00	18- 2	4X8-24535-00	24-13
5A1-21750-00	19- 1	4X8-24565-00	24-11
1Y1-2176A-00	19- 4	4U5-24610-00	24- 8
1Y1-21763-00	19- 3	5A1-24705-00	25-14
1Y1-21764-00	19- 2	5A1-24715-00	25- 5
3L5-21770-01	19- 5	1L9-24723-00	25- 8
5A1-21781-00	18- 4	5A1-24723-00	25-10
5A3-22110-00-33	20- 1	5A1-24728-00	25- 6
102-22123-00	20- 2	5A1-24731-00	25- 2
109-22141-00	20- 3	5A1-24738-00	25- 7
122-22151-00	20- 4	1L9-24741-00	25- 3
5A1-22210-01	20-16	1T4-24741-00	25- 4
5A1-22311-00	20- 6	5A1-24756-00	19-12
5A1-23100-00	23- 1	5A1-24760-00	25-15
5A1-23106-00-35	23- 4	109-25104-00	26-23
5A1-23107-00-35	23- 3	517-25111-00-35	26- 1
5A1-23110-00	23- 2	195-25115-00	26- 3
5A1-23116-00	22-21	195-25117-00	26- 2
5A1-23118-00	23-16	322-25118-00	26-30
4U5-23122-00	22-23	5A3-25121-00-35	26- 6
5A1-23125-00	23- 8	296-25135-00	26-10
5A1-23141-00	23-13	109-25136-00	26-11
5A1-23144-00	23-15	102-25137-00	26-34
5A1-23146-00	23- 9	296-25138-00	26-12
5A1-23318-00	23-19	183-25149-00	26-14
5A1-23327-00	22-19	538-25155-00	26-20
5A1-23328-00	22-20	353-25181-03	26-28
5A1-23340-00-33	23-12	296-25304-00	27-19
5A1-23408-00	22-17	462-25311-01-35	27- 1
156-23411-00	22- 1	102-25315-00	27- 3
183-23411-00	22- 6	1M3-25321-01-35	27-11

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
1F1-27860-00	21-12	122-83516-10	31- 3
260-28100-10	16-11	355-83519-02	31- 4
5A3-81300-20	3- 1	2W0-83520-00	31- 2
257-81309-21	3- 3	355-83522-00	31- 7
511-81312-20	3- 4	355-83526-00	31- 6
5A3-81313-20	3- 5	3R9-83550-50	31-10
5A4-81315-20	3- 9	214-83912-00	35- 2
2A6-81321-20	3- 6	233-83922-30	35- 9
1K8-81325-20	3- 7	437-83936-00	35-18
116-81331-20	3- 8	5A3-83973-00	35-15
110-81345-21	3-13	482-84110-00	32- 3
110-81346-21	3-11	317-84112-30	32- 8
110-81347-21	3-12	206-84114-60	32- 6
5A4-81350-20	3- 2	260-84120-00	32- 4
4F4-81910-60	34-14	150-84153-00	32- 2
353-81970-50	34- 8	241-84311-00-93	32- 1
353-81970-63	34- 8	195-84315-01	32- 5
355-81973-00	34-11	195-84324-00	32- 7
5A1-81975-00	34- 1	1X4-84510-90	33- 1
3K7-81980-C0	34-38	1X6-84511-00	33- 2
104-82110-29	34-18	1X4-84514-00	33- 5
104-82122-00	34-20	1X4-84517-00	34-44
1Y1-82131-00	34-21	1X4-84521-90	33- 3
353-82150-00	34-22	1X4-84524-90	33- 4
116-82151-00	34-23	1X4-84535-00	33- 6
355-82310-40	34-24	5A3-84551-90-93	33- 7
512-82370-10	34-26	90101-06278	26-21
5A1-82508-20	34-27		27-17
5A1-82514-00	34-28	90101-10514	23- 5
1J7-82530-00	34-33	90101-10521	20-19
5A1-82539-01	34-34	90105-10006	22- 4
136-82540-00	34-35	90109-06001	14-17
5A7-82571-01	34-29	90109-06410	35-10
5A3-82590-20	34-37	90109-06576	35- 5
498-82911-00	35- 1	90109-06617	34- 2
5A1-82920-10	35- 8	90109-08183	27-27
5A1-83310-10	30- 1	90109-08319	27- 8
152-83311-10	30- 3	90113-06009	11-22
	30- 8	90116-06026	1- 6
3M7-83312-10	30- 2	90119-05001	11- 9
	30- 7	90119-06016	25-13
1M1-83318-00	30- 4	90119-06017	22-16
5A1-83330-10	30- 6	90123-06010	28-26
3E1-83350-11	34-39	90123-08046	28-23
5A1-83352-00	34-40	90149-06011	24-18
469-83382-00	34-43	90149-08094	15- 4
3F4-83510-F0	31- 1	90152-05005	32- 9
1M3-83513-00	31- 5	90152-05009	22-18

PART NO.	REF. NO.
90157-05027	35-17
90167-03004	28-18
90170-08158	27-10
90170-10159	20- 5
90170-12060	11-11
90170-12175	3-17
90171-10004	26-32
90171-12005	27-34
90176-10013	20-18
90179-06143	28-27
90179-06176	29-12
90179-06337	1- 7
90179-08148	28-24
90179-12244	11-15
90179-25051	22- 5
90201-05029	17-23
90201-06008	25-12
90201-06075	24- 6
90201-062A8	34- 7
90201-06412	31- 8
90201-06557	19- 9
90201-07076	26-15
90201-08083	35-12
90201-082A9	35- 6
90201-08624	4-15
90201-10135	4-23
90201-10138	4-22
90201-10140	20-17
90201-103E6	23- 7
90201-103E9	23-14
90201-12535	3-15
90201-12575	15-10
90201-13202	10-19
90201-20269	26-16
90201-20279	20-13
90202-06010	24-19
90206-15021	10-20
90208-12015	11-10
	11-14
90209-10021	22- 3
90209-10108	10-16
90240-06009	20-14
90249-06005	21- 7
90249-12008	29-11
90250-06013	14-12
90251-07001	21- 6
90280-03017	2-15
90282-05005	11-13

PART NO.	REF. NO.
90334-10006	8- 3
90338-06018	17-25
90338-09012	28-30
90338-14120	17-19
90338-26008	8- 2
90340-12005	8-12
90387-07390	25- 9
90387-07392	25-11
90387-10277	26-29
90387-12412	27-36
90387-12670	27-37
90387-17139	5- 9
90430-04004	4- 7
90430-11034	34-36
90430-12038	8-13
90430-27165	22-22
90445-05013	6-33
90445-05015	6-34
90445-05019	4-12
90445-08171	34-19
90445-09089	24-15
90445-09115	24-14
90446-07009	8-15
90467-08003	19- 7
	24-16
90468-02033	4-11
	4-13
90468-12007	27-32
90468-26048	10- 3
90480-11224	18- 3
90480-12012	9-13
90480-12013	17-10
90480-13163	34-30
90480-13197	19-13
90480-13203	16- 7
90480-14052	19- 8
90501-02217	4- 9
90501-05512	28-17
90501-10078	13- 5
90501-10245	29-10
90501-12090	13- 3
90501-18464	21- 5
90501-20122	11- 8
90504-18005	10-15
90506-06095	5-21
90506-06106	5-17
90506-07066	11-26
90506-09009	15- 2

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
90506-09112	14-18	92901-05100	17- 8
90506-16150	26- 9		17-27
	27-13		33- 9
90506-20041	29- 7	92901-05200	34-12
90506-29054	29- 4	92901-05600	17- 6
90508-26136	10- 7		20- 8
90508-32207	15- 3		33- 8
90560-12170	27- 2		34-10
90560-17150	11-17	92901-06100	17-14
91401-12010	6-14		17-18
91401-16015	6-30		19-11
	20-15		27-40
91401-20015	27-30		28-29
	29-13		34- 4
91401-20020	26-33		34- 5
91401-30025	27-35		34-16
91609-40016	14- 3		34-42
91830-21014	9- 5	92901-06200	17-15
	9-12		17-20
91830-22016	8- 9	92901-06600	5-15
92501-06008	9-19		21- 9
92501-06012	12-16		27-41
	28-28		29-14
	34- 3		34-17
	34-41	92901-08100	7-11
92501-06014	5- 6		17- 3
	5- 8		17-12
	8-18		27-31
92501-06015	34-15		30- 9
92501-06018	6- 8		32-12
	9-17	92901-08200	27-29
92501-06030	8- 4	92901-10100	22-14
	9- 9		23-18
92501-06040	9- 3	92901-10200	20-20
	9-10	92901-10600	22-15
92501-06045	5-14		26-31
	8- 5	92901-12100	3-16
	9- 2	92903-06100	33-13
92501-06050	8- 6	92903-06600	33-12
	9- 4	92903-08600	32-11
	8-10	92906-05600	20-10
92501-06055	8- 8	92906-06100	16-10
92501-06060	25-16		25-17
92501-06065	34-32		35- 4
92506-06016	4- 4	92906-08100	35-14
92901-04100	7- 8	93101-10001	16- 6
92901-05100	14- 6	93101-12004	4-18
			15- 9

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
93102-17187	12-20	93501-04011	22- 9	97301-06016	17-17
93102-20009	2-13	93503-16010	11-19		19-10
93103-25078	8-17	93505-32002	4- 8		24- 7
93104-07003	26-13	93603-22028	4-21	97301-08012	17- 2
93104-21016	27- 6	93604-22050	14- 2	97301-08016	7-10
93105-47007	26- 7	93605-20043	14- 8	97303-06016	33-11
93106-20001	26- 4	94125-17259	26-25	97303-08020	32-10
93106-20002	27- 5		27-21	97306-06012	16- 9
93108-15001	11-29	94225-17105	26-26	97306-06022	35- 3
93109-15001	10-10		27-22		35-13
93110-27009	23-10	94330-17023	26-27	97311-06025	10-18
93210-10475	23- 6		27-23	97321-06014	17-13
93210-14104	26-35	94412-17002	26-24	97321-06020	15- 8
93220-08002	6- 6	94414-17003	27-20	97321-08016	17-11
93306-00203	13- 9	94504-10040	21-13	97321-10035	23-17
93306-20303	12-13	94580-13100	27-24	97602-03108	5- 4
93306-20418	2-12	94604-10001	21-14	97602-04125	3-10
93306-30003	26- 5	94604-20001	27-25	98501-04006	9- 7
93306-30101	27- 4	94701-00039	1- 3	98501-04012	34-31
93306-30301	12-14	95301-05600	4- 5	98501-05008	4-26
93306-30302	2-14		7- 9		20- 7
93310-11268	2- 9		17- 7	98501-05012	14- 5
	36- 5		17-24		17- 5
93310-41809	2- 6		34-13	98501-05016	4-17
	36- 4	95301-06600	21- 8	98501-05025	34- 9
93410-13004	10-23		26-22	98501-05030	35-16
	12- 6		27-18	98503-04010	5-19
	12-12		27-39	98506-05016	28- 7
93410-15005	10- 9		31- 9	98506-05020	20- 9
	13-11		33-14	98701-05016	3-14
93410-16007	12-19		34-25	98901-04008	4- 6
	13-10	95301-06700	11-23		
93410-20009	26-17	95301-08600	15- 5		
93410-25017	10- 5		30-10		
93430-08006	4-24	95301-08700	27-28		
	13- 8		32-13		
	14-15	95301-10600	22-13		
93430-10016	15-11	95302-05600	6-32		
93430-12008	29- 8	95303-08800	30- 5		
93430-15023	21-15	95601-06100	35-11		
93440-10028	10-17	95606-06100	35- 7		
93440-16030	12- 5	95701-06100	34- 6		
	12-17	95706-08100	16- 5		
	21-10	95826-08090	16- 3		
93440-25019	14- 9	95826-08100	16- 4		
93440-32017	2-11	95826-08120	16- 2		
93450-13022	23-11	97301-05010	33-10		
93450-40070	11-21	97301-05016	17-22		
93501-04011					

PARTS NAME INDEX

DESCRIPTION	REF. NO.
AXLE, main (13T)	12- 1
AXLE, Pedal	21- 3
AXLE, wheel	26-28
*	27-33
BACK MIRROR ASSY	28-31
BALL	4- 8
*	11-19
*	11-21
*	22- 9
BAND, battery	34-21
BAND, rim (3.00-17)	26-27
*	27-23
BAND, switch cord	35-18
BAR, shift fork guide	14-14
BAR, shift fork guide 1	14-13
BAR, tension	27-26
BAR, throttle	6-15
BASE, magne to	3- 3
BASE, taillight	33- 2
BATTERY ASSY (6N4A-4D)	34-18
BEARING (B6002)	13- 9
BEARING (B6203Z)	12-13
BEARING (B6204CS)	2-12
BEARING (B6300Z)	26- 5
BEARING (B6301)	27- 4
BEARING (B6303)	12-14
BEARING (B6303C3)	2-14
BEARING, cylindrical	2- 6
*	2- 9
*	36- 4
*	36- 5
BELL	34-43
BODY, float chamber 1	6- 7
BODY, headlight	32- 1
BOLT	7-10
*	10-18
*	14-17
*	15- 8
*	16- 9
*	17- 2
*	17-11
*	17-13
*	17-17
*	17-22
*	19-10
*	20-19
*	23- 5
*	23-17

PARTS NAME INDEX

DESCRIPTION	REF. NO.
BOLT	24- 7
*	26-21
*	27- 8
*	27-17
*	27-27
*	28-23
*	28-26
*	32-10
*	33-10
*	33-11
*	34- 2
*	35- 3
*	35- 5
*	35-10
*	35-13
BOLT, flange	16- 2
*	16- 3
*	16- 4
BOLT, set	11-22
BOLT, stud	1- 6
BOLT, washer based	22- 4
BOLT, with washer	11- 9
*	22-16
*	25-13
BOSS, clutch	11- 4
BRACKET, flasher relay 1	34-40
BRACKET, licence	33- 7
BRACKET, meter	31- 4
BRACKET, seat	25- 6
*	25- 7
BRAKE SHOE COMP.	26- 8
*	27-12
BREATHER	8-14
BULB (6V-10W)	30- 3
*	30- 8
BULB (6V-2W)	33- 5
BULB (6V-25/25W)	32- 6
BULB (6V-3W)	31- 3
BULB (6V-5W)	33- 6
BUSH	26-11
BUSH 1	20- 2
CABLE, brake	28-25
CABLE, clutch	28-21
CABLE, pump	28-10
CABLE, throttle 1	28- 8
CABLE, throttle 2	28- 9
CAMSHAFT	26-18
*	27-14

PARTS NAME INDEX

DESCRIPTION	REF. NO.
CAP ASSY	24- 8
CAP, cable connector	28-12
CAP, carburetor	5-20
CAP, grip lower	28- 6
CAP, grip upper	28- 5
CAP, mixing chamber	6-23
CAP, Plunger	6-26
CAP, rubber	28-19
CARBURETOR ASSY 1	6- 1
CASE, air cleaner 1	5-10
CASE, chain	20- 6
CHAIN, drive (DID410 40L)	21-13
CHAIN, drive (DID420M 100L)	27-24
CIRCLIP	2-11
*	4-24
*	10- 5
*	10- 9
*	10-17
*	10-23
*	12- 5
*	12- 6
*	12-12
*	12-17
*	12-19
*	13- 8
*	13-10
*	13-11
*	14- 9
*	14-15
*	15-11
*	21-10
*	21-15
*	23-11
*	26-17
*	29- 8
CLEANER, drain	5-22
CLIP	4-11
*	4-13
*	6-17
*	10- 3
*	19- 7
*	24-16
*	27-32
CLIP, Plunger	6-27
CLUTCH ASSY	11- 1
CLUTCH, meter	26-14
COIL, lighting 1	3- 5
COIL, source	3- 4

PARTS NAME INDEX

DESCRIPTION	REF. NO.
COLLAR	5- 9
*	25- 9
*	25-11
*	26-29
*	27-36
*	27-37
*	31- 7
COLLAR, rectifier	34-11
CONDENSER 1	3- 7
CONNECTING ROD ASSY	36- 1
CONNECTOR, cable	28-11
CONTACT BREAKER ASSY	3- 6
CORD, taillight	34-44
COVER 1	5-18
COVER, ball race 1	22-10
COVER, carburetor	9-15
COVER, chain case 2	9-18
COVER, crankcase 1	9- 1
COVER, crankcase 2	9- 8
COVER, double seat	25- 2
COVER, generator	9- 6
COVER, hub dust	26-30
COVER, kick lever	10-14
COVER, outer 1	22-23
COVER, Pedal	21-16
COVER, Plunger cap	6-28
COVER, rear footrest	20-12
COVER, shift Pedal	15- 7
COVER, side 1	18- 1
COVER, side 2	18- 2
COVER, sPring	10- 8
COVER, tail	19-12
CRANK 1	2- 2
CRANK 2	2- 3
CRANK, Pedal	21- 1
CRANKCASE 1	8- 1
CRANKCASE 2	8-11
CRANKSHAFT ASSY	2- 1
CROWN, handle	22- 2
CYLINDER 1	1- 4
DAMPER	31- 5
DAMPER 2	31- 6
DAMPER, locating 1	24- 3
*	24- 4
DAMPER, locating 2	24- 5
DAMPER, seat	25- 8
*	25-10
DAMPER, side cover	17-26

PARTS NAME INDEX

DESCRIPTION	REF. NO.
DIODE	34-38
DOG, transmission shift	13- 2
DOUBLE SEAT ASSY	25- 1
DRIVE AXLE ASSY	12- 7
ELEMENT, air cleaner	5-11
EMBLEM	9-20
*	9-21
EMBLEM 1	18- 4
*	24-17
END, cable	28-22
FLANGE, sPacer	27- 3
FLANGE, sPacer 1	26- 3
FLAP	17-21
FLASHER RELAY ASSY	34-39
FLOAT	6- 4
FLYWHEEL MAGNETO ASSY	3- 1
FOOTREST, rear 1	20-11
FORK, shift 1	14-10
FORK, shift 2	14-11
FORK, transmission shift	13- 4
FRAME COMP.	16- 1
FRONT FENDER COMP.	17- 1
FRONT FLASHER LIGHT ASSY 1	30- 1
FRONT FORK ASSY	23- 1
FUEL COCK ASSY 1	24- 9
FUEL TANK COMP.	24- 1
*	24- 1
FUSE (6V-10A)	34-23
FUSE HOLDER ASSY	34-22
GASKET	4- 7
*	8-13
*	22-22
*	24-11
*	24-12
*	34-36
GASKET, carburetor cover 2	9-16
GASKET, crankcase cover	9-11
GASKET, cylinder	1- 5
GASKET, cylinder head 1	1- 2
GASKET, exhaust PiPe	7- 3
GASKET, float chamber	6- 5
GASKET, level gauge	19- 3
GASKET, muffler	7- 4
GASKET, Pump case	4-16
GASKET, valve seat	5- 5
GEAR, drive	26-10
GEAR, kick (26T)	10- 2
GEAR, kick idle (26T)	10-21

PARTS NAME INDEX

DESCRIPTION	REF. NO.
GEAR, meter	26-12
GEAR, Primary drive (19T)	11-12
GEAR, Pump drive (30T)	4-20
GEAR, 1st wheel (40T)	12- 8
GEAR, 2nd Pinion (18T)	12- 2
GEAR, 2nd wheel (34T)	12- 9
GEAR, 3rd Pinion (23T)	12- 3
GEAR, 3rd wheel (30T)	12-10
GEAR, 4th Pinion (26T)	12- 4
GRAPHIC SET	24- 2
GRIP (L.H)	28- 4
GRIP (R.H)	28- 2
GROMMET	9-13
*	16- 7
*	17-10
*	18- 3
*	19- 8
*	19-13
*	34-30
GROMMET, wireherness	32- 2
GUIDE	5-12
GUIDE, cable	16- 8
GUIDE, cover lower	22-21
GUIDE, rotor	28-14
GUIDE, sPring	10- 6
HANDLEBAR	28- 1
HEAD, cylinder 1	1- 1
HEADLIGHT UNIT ASSY	32- 3
HOLDER	6-29
HOLDER, cable	17- 4
HOLDER, cable cylinder	28-20
HOLDER, cable 1	23-19
HOLDER, handle lower	22-12
HOLDER, handle upper	22-11
HOLDER, lever 1	35- 1
HOOK, sPring	11-27
HOSE	4-12
*	6-33
*	6-34
*	8-15
*	24-14
*	24-15
*	34-19
HOUSING, oil seal	8-16
HUB, front	26- 1
HUB, rear	27- 1
IGNITION COIL ASSY	34-24
INNER TUBE COMP.1	23- 2

PARTS NAME INDEX

DESCRIPTION	REF. NO.
JET, main (#120)	6- 3
JET, main (#125)	6- 3
JET, main (#130)	6- 3
JET, Pilot (#25.0)	6-12
JOINT, air cleaner 1	5-16
JOINT, chain	21-14
*	27-25
JOINT, Pump	5- 7
KEY, straight	11-13
KEY, woodruff	2-15
KICK AXLE ASSY	10- 1
KICK CRANK ASSY	10-12
KNOB, transmission shift	13- 7
LEAD WIRE ASSY	3- 9
LENS ASSY	32- 4
LENS, flasher	30- 2
*	30- 7
LENS, level gauge	19- 2
LENS, taillight	33- 3
LEVER HOLDER ASSY 2	35- 8
LEVER 1	35- 2
LEVER 2	35- 9
LEVER, camshaft	27-16
LEVER, camshaft 1	26-20
LEVER, kick	10-13
LEVER, Push	11-25
LEVER, transmission shift	13- 6
LINK, main stand	29- 3
LUBRICATOR	3- 8
MAIN SWITCH ASSY	34-27
METAL, slide 1	23- 8
METAL, worm shaft outer	4-19
MUFFLER ASSY 1	7- 6
NEEDLE	6-13
NEEDLE VALVE ASSY	6- 9
NEUTRAL SWITCH ASSY	34-35
NOZZLE	4-10
NOZZLE, main	6- 2
NUT	1- 7
*	3-17
*	4- 5
*	6-32
*	7- 9
*	11-11
*	11-15
*	11-23
*	15- 5
*	17- 7

PARTS NAME INDEX

DESCRIPTION	REF. NO.
NUT	17-24
*	20- 5
*	21- 8
*	22- 5
*	22-13
*	26-22
*	27-10
*	27-18
*	27-28
*	27-39
*	28-24
*	28-27
*	29-12
*	30-10
*	31- 9
*	32-13
*	33-14
*	34-13
*	34-25
NUT, castle	26-32
*	27-34
NUT, crown	20-18
*	30- 5
NUT, flange	16- 5
*	34- 6
NUT, muffler joint	7- 5
NUT, ring	7- 2
NUT, u	35- 7
*	35-11
O-RING	6- 6
*	23- 6
*	26-35
OIL PUMP ASSY	4- 1
OIL SEAL	2-13
*	4-18
*	8-17
*	10-10
*	11-29
*	12-20
*	15- 9
*	23-10
*	26- 4
*	26- 7
*	26-13
*	27- 5
*	27- 6
OIL TANK ASSY	19- 1
OIL TANK CAP ASSY	19- 5

PARTS NAME INDEX

DESCRIPTION	REF. NO.
OUTER TUBE COMP. (L.H)	23- 4
OUTER TUBE COMP. (R.H)	23- 3
PAD, seat	25- 3
*	25- 4
PANEL, switch	34-29
PEDAL ASSY (L.H)	21-11
PEDAL ASSY (R.H)	21-12
PEDAL, brake	29- 6
PEDAL, crank (R.H)	21- 2
PEDAL, shift	15- 6
PIN	21- 7
*	28-16
*	29-11
PIN, clevis	20-14
PIN, cotter	6-14
*	6-30
*	20-15
*	26-33
*	27-30
*	27-35
*	29-13
PIN, crank 1	2- 5
*	36- 3
PIN, dowel	4-21
*	8- 9
*	9- 5
*	9-12
*	14- 2
*	14- 8
PIN, piston	2-10
PIN, spring	14- 3
PIN, straight	14-12
PIN, tapered	21- 6
PIPE, exhaust 1	7- 1
PIPE, oil	19- 6
PIPE, shaft	21- 4
PISTON (STD)	2- 7
PISTON (1ST O/S 0.25MM)	2- 7
PISTON (2ND O/S 0.50MM)	2- 7
PISTON RING SET (STD)	2- 8
PISTON RING SET (1ST O/S)	2- 8
PISTON RING SET (2ND O/S)	2- 8
PLATE, adjusting	4- 3
PLATE, brake shoe	26- 6
*	27-11
PLATE, clutch 1	11- 6
PLATE, cover	12-15
PLATE, friction	11- 5

PARTS NAME INDEX

DESCRIPTION	REF. NO.
PLATE, indicator	26-19
*	27-15
PLATE, Pressure 1	11- 7
PLATE, rectifier fitting	34- 1
PLATE, side 1	14- 4
PLATE, thrust 2	11- 3
*	11-16
PLUG	8- 2
*	17-19
*	17-25
*	28-30
PLUG CAP ASSY	34-26
PLUG, oil level	9-14
PLUG, sPark (NGK B6HS)	1- 3
PLUG, straight	8- 3
PLUG, straight screw	8-12
PLUNGER, starter	6-24
POINT, neutral	14- 7
PRIMARY DRIVEN GEAR COMP.	11- 2
PULLER, chain 2	27-38
RACE, ball 1	22- 1
*	22- 6
RACE, ball 2	22- 7
*	22- 8
REAR ARM COMP.	20- 1
REAR FENDER COMP.	17- 9
REAR FLASHER LIGHT ASSY 1	30- 6
RECTIFIER ASSY	34- 8
*	34- 8
REED VALVE ASSY	5- 1
REED, valve	5- 2
REFLECTOR, level gauge	19- 4
RIM (1.20-17)	26-24
RIM (1.40-17)	27-20
RIM, headlight	32- 5
RING, stop	26-34
ROD, brake	29- 9
ROD, connecting	2- 4
*	36- 2
ROD, Push 1	11-18
ROD, Push 2	11-20
ROTOR	28-13
ROTOR ASSY	3- 2
SCREW	6-31
*	15- 4
*	24-18
SCREW, air adjusting	6-10
SCREW, bind	4- 6

PARTS NAME INDEX

DESCRIPTION	REF. NO.
SCREW, countersunk	22-18
*	32- 9
SCREW, flat head	3-14
SCREW, lens fitting	33- 4
SCREW, lever fitting	24-13
SCREW, Pan head	3-11
*	3-12
*	3-13
*	4-17
*	4-26
*	5- 6
*	5- 8
*	5-14
*	5-19
*	6- 8
*	8- 4
*	8- 5
*	8- 6
*	8- 7
*	8- 8
*	8-10
*	8-18
*	9- 2
*	9- 3
*	9- 4
*	9- 7
*	9- 9
*	9-10
*	9-17
*	9-19
*	12-16
*	14- 5
*	17- 5
*	20- 7
*	20- 9
*	25-16
*	28- 7
*	28-28
*	34- 3
*	34- 9
*	34-15
*	34-31
*	34-41
*	35-16
*	35-17
SCREW, Pan head with washer	3-10
*	5- 4
SCREW, Push	11-24

PARTS NAME INDEX

DESCRIPTION	REF. NO.
SCREW, tapping	28-18
SCREW, throttle stop	6-21
SEAL, cock	24-10
SEAL, dust	23-15
SEAL, guard	20- 4
SEAL, Push rod	11-28
SEAT LEVER ASSY	25-15
SEAT LOCK ASSY	25-14
SEAT, battery	34-20
SEAT, sPring	6-18
SHAFT, main stand	29- 2
SHAFT, Pivot	20- 3
SHAFT, worm	4-14
SHIFT CAM ASSY	14- 1
SHIFT SHAFT ASSY	15- 1
SHIM	10- 4
SHIM (0.3T)	4- 2
SHIM (0.5T)	4- 2
SHIM (0.6T)	12-11
SHIM (1.0T)	4- 2
SHOCK ABSORBER ASSY, rear	20-16
SILENCER, exhaust	7- 7
SLIDER, throttle	28-15
SOCKET	32- 8
SOCKET CORD ASSY	31- 2
SPACER	11-17
*	23-16
*	27- 2
SPACER, bearing	26- 2
SPEEDOMETER ASSY	31- 1
SPEEDOMETER CABLE ASSY	31-10
SPOKE SET, front	26-23
SPOKE SET, rear	27-19
SPRING, air adjusting	6-11
SPRING, compression	4- 9
*	10-15
*	11- 8
*	13- 3
*	13- 5
*	21- 5
*	28-17
*	29-10
SPRING, front fork	23-13
SPRING, Plunger	6-25
SPRING, reflector	32- 7
SPRING, tension	5-17
*	5-21
*	11-26

PARTS NAME INDEX

DESCRIPTION	REF. NO.
SPRING, tension	14-18
*	15- 2
*	26- 9
*	27-13
*	29- 4
*	29- 7
SPRING, throttle stop	6-20
SPRING, throttle valve	6-19
SPRING, torsion	10- 7
*	15- 3
SPROCKET, drive	13- 1
SPROCKET, drive (11T)	12-18
SPROCKET, drive (12T)	12-18
SPROCKET, drive (13T)	12-18
SPROCKET, driven (44T)	27- 7
SPROCKET, driven (45T)	27- 7
SPROCKET, driven (46T)	27- 7
STAND, main	29- 1
STAY	4-25
STAY 1	5-13
STAY, flasher	22-19
*	22-20
STAY, flasher 1	30- 4
STAY, front	25- 5
STAY, main switch	34-28
STAY, rear	17-16
STAY, stop switch	34-34
STEERING LOCK ASSY	22-17
STOP SWITCH ASSY	34-33
STOPPER	10-11
STOPPER LEVER ASSY	14-16
STOPPER, main stand	29- 5
STOPPER, reed valve	5- 3
SWITCH, handle 3	35-15
TAILLIGHT UNIT ASSY	33- 1
TIRE (2.50-17)	26-25
*	27-21
TOOL KIT	16-11
TOP, mixing chamber	6-22
TUBE (2.50-17)	26-26
*	27-22
TUBE, throttle guide	28- 3
UNDER BRACKET COMP.	23-12
VALVE, throttle 1	6-16
VOLTAGE REGULATOR ASSY ..	34-14
WASHER	10-16
*	10-22
*	10-22

PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER	10-22
*	22- 3
*	27- 9
WASHER, conical spring	11-10
*	11-14
WASHER, oil seal	23- 9
WASHER, Plain	17-15
*	17-20
*	20-20
*	27-29
*	34-12
WASHER, Plate	3-15
*	4-15
*	4-22
*	4-23
*	5-15
*	10-19
*	15-10
*	17- 6
*	17-23
*	19- 9
*	20- 8
*	20-10
*	20-13
*	20-17
*	21- 9
*	22-15
*	23- 7
*	23-14
*	24- 6
*	24-19
*	25-12
*	26-15
*	26-16
*	26-31
*	27-41
*	29-14
*	31- 8
*	32-11
*	33- 8
*	33-12
*	34- 7
*	34-10
*	34-17
*	35- 6
*	35-12
WASHER, spring	3-16
*	4- 4

PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER, spring	7- 8
*	7-11
*	14- 6
*	16- 6
*	16-10
*	17- 3
*	17- 8
*	17-12
*	17-14
*	17-18
*	17-27
*	19-11
*	22-14
*	23-18
*	25-17
*	27-31
*	27-40
*	28-29
*	30- 9
*	32-12
*	33- 9
*	33-13
*	34- 4
*	34- 5
*	34-16
*	34-32
*	34-42
*	35- 4
*	35-14
WASHER, wave	10-20
WIRE HARNESS ASSY	34-37

COPY RIGHT: ALL RIGHTS RESERVED
NO PART OF THIS PUBLICATION MAY BE
REPRODUCED WITHOUT PERMISSION.

JMPB

parts



YAMAHA

YAMAHA MOTOR CO., LTD.
2500 SHINGAI IWATA-SHI SHIZUOKA-KEN JAPAN

PRINTED IN JAPAN

First edition Oct., 1981

T6